


Installation Precautions:

- 1. Please read through the Instructions before installation.
- 2. The product should be installed by a professional electrician.
- 3. Make sure the power supply is cut off before installation and maintenance, to avoid the risk of electric shock.
- 4. The light can be recessed on the ceiling, where sufficient space must be reserved for installation. Do not cover the light with any thermal insulation or consumable articles to avoid fire hazards.
- 5. In case of cracking of glass, please replace it immediately.
- 6. Do not install the light on an unstable or unsolid skylight, to avoid falling off.
- 7. Please keep this Instruction properly for future reference.
- 8. The LED source in the light should be replaced by the manufacturer or its service agent or similarly qualified personnel.

Light Installation and Wiring:



- * If the driver of the light comes with lead wires, and the leads need to be connected with an independent terminal block (refer to Figure 3 for wiring), the size of the terminal block for each line should not be less than 10x20x25mm.
- * The lamp without driver comes with red and black lead wires, and it cannot be directly connected to 220V AC. Customer-provided driver shall match the specification of LED source.

Licensed by "WAC" trademark holder - WAC LIGHTING, USA

Chinese Marketing Headquarters : WAC Lighting (Shanghai) Co, Ltd.

Address : 14,Lane 299, Bi Sheng Road, Shanghai 201204,China China factory : Manufactured WAC Lighting (Dongguan) Co, Ltd.


Address : 390, Qingfeng Road, Qingxi Town, Dngguan, Guangdong. Postal code: 523653



Installation Precautions:

- 1. Please read through the Instructions before installation.
- 2. The product should be installed by a professional electrician.
- 3. Make sure the power supply is cut off before installation and maintenance, to avoid the risk of electric shock.
- 4. The light can be recessed on the ceiling, where sufficient space for must be reserved for installation. Do not cover the light with any thermal insulation or consumable articles to avoid fire hazards.
- 5. In case of cracking of glass, please replace it immediately.
- 6. Do not install the light on an unstable or unsolid skylight, to avoid falling off.
- 7. Please keep this Instruction properly for future reference.
- 8. The LED source in the light should be replaced by the manufacturer or its service agent or similarly qualified personnel.

Light Installation and Wiring:



- * If the driver of the light comes with lead wires, and the leads need to be connected with an independent terminal block (refer to Figure 3 for wiring), the size of the terminal block for each line should not be less than 10x20x25mm.
- * The lamp without driver comes with red and black lead wires, and it cannot be directly connected to 220V AC. Customer-provided driver shall match the specification of LED source.